



- NOTES:
- 1) USE THESE TEMPLATES AT YOUR OWN RISK! NO CLAIM OF SUITABILITY FOR ANY SPECIFIC PURPOSE IS MADE.
 - 2) GLUE THESE TEMPLATES TO $\frac{3}{32}$ " AIRCRAFT GRADE PLYWOOD WITH SPRAY ADHESIVE AND CUT TO OUTER LINE WITH BANDSAW OR JIGSAW. SAND TO PERFECTION WITH A SANDING BLOCK. LEAVE THE "HUMPS" IN PLACE UNTIL TEMPLATES ARE GLUED TO SPARS, THEN REMOVE. (SEE <http://home.hiwaay.net/~langford/kht.html>).
 - 3) THE INNER LINES ARE OFFSET .030" TO SERVE AS A GUIDE IF YOU ACCIDENTLY REMOVE THE OUTER TEMPLATE LINES.
 - 4) ALL DIMENSIONS NOT SHOWN ON THIS DRAWING ARE TO BE PER RR PLANS. FOR MORE INFORMATION NOTE THAT TALLER HORIZONTAL STAB SPARS ARE REQUIRED.

SCALE- THIS LINE IS TWELVE INCHES LONG